T02T90 "00S2T860

FIG - 1
PRIOR ART



1022150 005260

FIG - 2A
PRIOR ART



FIG - 2B
PRIOR ART



FIG - 3
PRIOR ART



T02T90'0052T860

FIG - 4A
PRIOR ART





FIG - 4B
PRIOR ART

F02F90 00526050



FIG - 5

FIG - 6A


Open Control Framework
File Edit Project Window Help
Flow Chart: Air_Pressure
0
1
2
3
4
5
6
7
154
150
158
Start
160
Scale the Analog Input
162
Air Pressure too low
Else
Then
156
Errors = 34 TURN ON
Ready
Start
MAJ
Document WordPad
Open Control Framework
3:51 PM

FIG - 6B


Open Control Framework
File Edit Project Window Help
Flow Chart: Air_Pressure
0
1
2
3
4
5
6
7
Air Pressure too low
Else
Then
Errors = 34
TURN ON
Return
Ready
Start
MAJ
Document WordPad
Open Control Framework
3:51 PM
154
150
156

T02T90*00527860

FIG - 7



t02t90*00521860

FIG - 8